

# Building Energy Rating (BER)

BER for the building detailed below is:

**D1**


**Address**  
4 WILLOW GROVE  
CARNAMUGGAGH  
LETTERKENNY  
CO. DONEGAL

**BER Number** 108170242  
**Date of Issue** 05/12/2015  
**Valid Until** 05/12/2025  
**Assessor Number** 104428  
**Assessor Company No** 104428

The Building Energy Rating (BER) is an indication of the energy performance of this dwelling. It covers energy use for space heating, water heating, ventilation and lighting, calculated on the basis of standard occupancy. It is expressed as primary energy use per unit floor area per year (kWh/m<sup>2</sup>/yr).

'A' rated properties are the most energy efficient and will tend to have the lowest energy bills.

**Building Energy Rating**  
kWh/m<sup>2</sup>/yr  
**MOST EFFICIENT**



**Carbon Dioxide (CO<sub>2</sub>) Emissions Indicator**  
kgCO<sub>2</sub>/m<sup>2</sup>/yr

**BEST**

0

Calculated annual CO<sub>2</sub> emissions

61.98 kgCO<sub>2</sub>/m<sup>2</sup>/yr

**WORST**

>120

The less CO<sub>2</sub> produced, the less the dwelling contributes to global warming.

**IMPORTANT:** This BER is calculated on the basis of data provided to and by the BER Assessor, and using the version of the assessment software quoted below. A future BER assigned to this dwelling may be different, as a result of changes to the dwelling or to the assessment software.



## Building Energy Rating (BER) ADVISORY REPORT

Energy use in our homes is responsible for more than a quarter of Ireland's total CO<sub>2</sub> emissions. Reducing energy use will save you money and is good for the environment. This report provides advice on improving your Building Energy Rating, reducing your energy usage and costs, while improving the comfort and condition of your home.

**Report Date:** 05/12/2015

**Assessor:** Adrian McGettigan  
**Address:** 4 WILLOW GROVE  
CARNAMUGGAGH  
LETTERKENNY  
CO. DONEGAL

**BER:** 108170242  
**MPRN:** 10017026306

### About this Advisory Report

Energy use in our homes is responsible for almost a quarter of Ireland's total CO<sub>2</sub> emissions. Reducing energy use will save you money and is good for the environment. This report provides advice on improving your BER, reducing your energy usage and costs, while improving the comfort of your home. The improvement measures recommended in this report are not mandatory and can be completed at your own discretion. Some improvements may require the use of suitably qualified installers or professional advice. All works should be completed to the relevant health and safety standards. Where applicable, works should be completed to the relevant Building Regulations.

In this report an associated cost and impact are provided for the recommendations specific to your home. Costs and impacts are divided into categories and these are defined as follows:

**Low Cost** are improvements that are expected to cost less than 100 euro to complete.

**Medium Cost** are improvements that are expected to cost 100 euro to 1,000 euro to complete.

**High Cost** are improvements that are expected to cost more than 1,000 euro to complete.

The above costs are guidelines only and actual costs will vary depending on house size, work specification and market conditions.

**Low Impact** are measures that will make a small improvement in energy efficiency.

**Medium Impact** are measures that will make a medium improvement in energy efficiency.

**High Impact** are measures that will make a large improvement in energy efficiency. Implementing any improvement measure will reduce your energy consumption. When implementing improvements it is sensible to prioritise those with a low cost and a high impact first. The money saved by reducing energy usage can help to pay for the

improvement measures. Moreover apart from increasing the comfort and costs the measures could increase the value of your home and reduce its environmental impact.

## Ventilation

General Operational Advice on Ventilation

Care should always be taken to ensure a sufficient level of ventilation to maintain fresh air levels in each room and to remove moisture, water vapour and pollutants. For health and safety reasons it is important to ensure an adequate air supply to combustion appliances e.g. gas, oil or solid fuel. Signs of inadequate ventilation are persistent condensation and mould growth. If such problems exist, they should be addressed first, since reducing ventilation may make the problem worse. In a typical home 20% of all heat loss is through ventilation and draughts. Energy consumption can be improved while maintaining adequate ventilation. If draught sealing is damaged at any time make sure to replace it. When draughtproofing or making houses more airtight, it is important to maintain recommended ventilation standards. Radon concentrations can increase in existing houses as a result of greater airtightness. Further information on Radon is available from the Radiological Protection Institute of Ireland in their publication "Radon in Homes". This guide can be downloaded from [www.rpii.ie](http://www.rpii.ie).

## Chimneys

This dwelling has one or more chimneys.

The chimney(s) in this dwelling increase heat loss by allowing heated air to escape. When making improvements it is important for safety reasons to ensure that proper ventilation is provided in rooms with combustion appliances. There are 3 upgrade options available to you to reduce the heat loss through the chimney(s):

(a) Installing a closed-in stove will reduce heat losses, and will also be approximately twice as efficient as an open fire, giving the same heat for half as much fuel.

**Cost:** High    **Impact:** Medium

(b) Supplying outside air directly to the heating appliance instead of drawing heated air from the room will reduce heat loss in the room. If possible, the appliance should be room sealed i.e. takes its air supply directly from outside. This will eliminate all air exchange with the room in which it is situated.

**Cost:** High    **Impact:** Low

(c) Installing a chimney damper will reduce heat losses when the fireplace is not in use. If the chimney is never used it can be permanently sealed which involves installing a permanent insulated panel. An adjustable vent should be incorporated into the panel to avoid the chimney space becoming damp.

**Cost:** Medium    **Impact:** Low

## Fan & Vents

This dwelling has one or more fans/vents.

The fans and vents in this dwelling increase heat loss by allowing heated air to escape but can be important in ensuring adequate ventilation.

If there is no cover on the inside of the vents, installing controllable vent covers will

allow you to control the air flow through the vents, and so can help reduce heat loss. It is important not to permanently close or cover over air vents as they are required to provide ventilation for the removal of moisture, pollutants and operation of combustion appliances. It is important for safety reasons to have proper ventilation in any room which contains combustion appliances. For further details please refer to publication 'A Detailed Guide to Insulating Your Home' available on [www.seai.ie](http://www.seai.ie).

**Cost:** Low    **Impact:** Low

### **Draught Lobby**

This dwelling has no draught lobby.

Open doors and air gaps around doorways are a source of heat loss in a dwelling.

The construction of a draught lobby/porch on the frequently used external doorways in this dwelling would reduce these heat losses. Lobbies should be constructed to the relevant Building Regulations. Care should be taken not to block any existing ventilation openings inadvertently.

**Cost:** High    **Impact:** Low

### **Suspended Wooden Floor**

This dwelling has a solid floor.

No specific action is advised.

### **Draught Stripping**

This dwelling has 100% draught stripping.

No specific action is advised.

### **Ventilation System**

This dwelling has natural ventilation.

No specific action is advised.

## **Building Elements**

### **Floors**

General Operational Advice on Floors

Floors can be a source of significant heat loss and dampness in a dwelling. For example heat loss through the ground floor of a two storey house typically accounts for about 10% of total heat loss. For a single storey house this figure is about 15%. However, if a house is well insulated everywhere except for the ground floor, this percentage will be higher. A U-Value is a measure of the heat loss through the fabric of the building. The lower the U-Value the better and the higher the U-Value the greater the heat loss. Floors with a U-Value greater than 0.25 could be improved in a number of ways. A relatively simple way to reduce heat loss through a ground floor is to lay a carpet with foam backing or a foam underlay ensuring that both carpet and underlay are laid wall to wall. Sealing of gaps in the ground floor will help to reduce draughts. Modern insulation methods for new houses may also be implemented in existing houses. In some cases this would be disruptive and costly, but if work needs to be done on the floor anyway, this is a good time to consider an insulation upgrade. For further details please refer to publication 'A Detailed Guide to Insulating Your Home' available on [www.seai.ie](http://www.seai.ie)

Part of the floor area in this dwelling has a U-Value of less than 0.6 and greater than 0.25.

The insulation in this floor can be improved.

**Cost:** High    **Impact:** Low

## Roofs

### General Operational Advice on Roofs

Proper insulation will help retain valuable heat and improve overall comfort levels. If insulation is disturbed or damaged at any time, e.g. in attic space, make sure to restore or replace it.

Heat loss through an un-insulated roof of a typical house can account for up to 30% of the total heat loss. Installing insulation will reduce this heat loss, and hence reduce the energy demand of the dwelling. A U-Value is the measure of the heat loss through the fabric of the building. The lower the U-Value the better and the higher the U-Value the greater the heat loss. Modern pitched roofs or habitable roof spaces that are insulated between the rafters, have a U-Value less than or equal to 0.2. Modern flat and pitched roofs that are insulated at ceiling level, have a U-Value less than or equal to 0.16. Blanket insulation, rigid board insulation or expanding foam may be used to achieve the required insulation level. Loose beads may also be used for roofs insulated on the ceiling. Installing roof insulation generally involves a considerable amount of work. The attic/roof space must have adequate ventilation to prevent dampness. This is achieved by leaving a continuous air gap along the eaves at each side. Electric cables should not be buried under insulation. Leave clearance for recessed lights to avoid them overheating. For further details please refer to publication 'A Detailed Guide to Insulating Your Home' available on [www.seai.ie](http://www.seai.ie)

Part of the pitched roof insulated on the rafter or room in roof in this dwelling has a U-Value of less than 1.5 and greater than or equal to 0.4.

The insulation in this roof can be significantly improved.

**Cost:** High    **Impact:** Medium

Part of the pitched roof insulated on the ceiling in this dwelling has a U-Value of less than 1.5 and greater than or equal to 0.4.

The insulation in this roof can be significantly improved.

**Cost:** Medium    **Impact:** Medium

## Walls

Heat loss through the walls can account for up to 30% of the total heat loss. This can typically be reduced by two-thirds by insulating the walls and so reduce the energy demand of the dwelling. A U-Value is a measure of the heat loss through the building fabric. The lower the U-Value the better and the higher the U-Value the greater the heat loss. Walls with a U-Value greater than 0.27 could be improved. Insulation may be installed as cavity fill. This is where the gap between the inner and outer layers of external walls is filled with an insulating material. If cavity insulation is not applicable or is not technically possible, insulation may be installed internally or externally. Internal insulation involves a layer of insulation being fixed to the inside surface of external

walls, and a suitable fire resistant finish being incorporated or applied. External solid wall insulation is the application of an insulant and a weather-protective finish to the outside of the wall.

For further details please refer to publication 'A Detailed Guide to Insulating Your Home' available on [www.seai.ie](http://www.seai.ie)

Part of the wall area in this dwelling has a U-Value of less than 0.6 and greater than 0.27.

The insulation in this wall can be improved.

**Cost:** High    **Impact:** Low

### Windows

Glass allows heat to escape more readily than most other building materials. For this reason, it is important that the windows are as energy efficient as possible. Windows can account for around 15% of the heat loss in your home. Installing energy efficient windows such as low-E double glazing helps to retain heat and improves comfort through elimination of cold window surfaces and associated draughts and condensation. The use of shutters, lined curtains and blinds can improve heat retention at night and further reduce draughts.

A U-Value is a measure of the heat loss through the building fabric. The lower the U-Value the better and the higher the U-Value the greater the heat loss. Windows with a heat loss greater than the current building standards (i.e. have a U-Value greater than 2) could be improved. The best benefits are achieved through replacing single glazed windows with low-E double glazing or triple glazing.

Note that single glazing can also be improved by adding secondary glazing (installing a secondary window and frame on the room side of the existing window).

Some of the windows in this dwelling with a U-Value of less than 4 and greater than or equal to 2.7.

The heat loss through these windows can be significantly reduced.

**Cost:** High    **Impact:** Medium

### Doors

Heat is lost from dwellings through doors which often have relatively poor thermal insulation compared to other elements of the building. Installing insulated doors will reduce this heat loss, and also generally reduce draughts through air gaps at the frames. Replacement doors, whether glazed or half glazed, should have insulated cores. A U-Value is a measure of the heat loss through the fabric of the building. The lower the U-Value the better and the higher the U-Value the greater the heat loss.

Doors with a U-Value greater than 2.0 could be improved. For further details please refer to publication 'A Detailed Guide to Insulating Your Home' available on [www.seai.ie](http://www.seai.ie)

Part of the door area in this dwelling has a U-Value of less than 4 and greater than or equal to 2.7.

The heat loss through this door area can be significantly reduced.

**Cost:** Medium    **Impact:** Low

## **Hot Water**

General Operational Advice on Hot Water.

Ensure that the hot water cylinder insulation is not disturbed or damaged. Incomplete insulation increases heat loss and costs money.

### **Hot Water Primary Circuit Losses**

The hot water system in this dwelling has no cylinder thermostat.

In general, the simplest improvement that can be made is to install a cylinder thermostat to reduce unnecessary heat loss from the primary pipework. Uncontrolled heat loss can also be reduced by installing insulation on hot water distribution pipework where heating is not required. This reduces the amount of heat required to be generated by the heating system, and so reduces the amount of fuel required. Ideally, this involves all pipework (flow and return) between the boiler and hot water cylinder being insulated (including in walls and floors).

**Cost:** Medium    **Impact:** Low

### **Hot Water Cylinder Insulation**

The hot water cylinder insulation is less than 80mm.

Installing a cylinder lagging jacket of at least 80mm thickness reduces hot water storage heat losses. If the cylinder is reaching the end of its useful life, consider replacing it with a preinsulated cylinder model.

**Cost:** Low    **Impact:** High

### **Cylinder Timer / Thermostat**

The hot water cylinder in this dwelling should have both a cylinder timer and cylinder thermostat.

Consider installing a hot water cylinder timer and thermostat to reduce unnecessary heat loss from the hot water cylinder. A hot water cylinder thermostat enables the boiler to switch off when the water in the cylinder reaches the required temperature. This minimises the amount of energy that is used and lowers fuel bills.

The best setpoint for the thermostat is 60°C. Setting the temperature lower than this presents a health risk. Setting the temperature higher than this wastes energy.

**Cost:** Medium    **Impact:** Low

## **Lighting**

General Operational Advice on Lighting

Compact Fluorescent Lamps (CFLs) use 20% of the energy used by typical incandescent bulbs to give the same amount of light. A 22 Watt CFL has the same light output as a 100 Watt incandescent. LED (Light-emitting diode) lights use less than 10% of the energy required for corresponding tungsten lights. Low energy lighting will give highest savings in rooms that are most often used.

### **Lighting - Low Energy Bulbs**

The low energy lighting in this dwelling is greater than or equal to 50% but but less than 100%.

Replacement of traditional light bulbs (tungsten or incandescent) with energy saving bulbs (CFL or LED) can reduce lighting costs significantly. They also last considerably longer than ordinary light bulbs thereby saving on replacement costs. Consider

replacing traditional light bulbs with energy saving bulbs.

**Cost:** Low    **Impact:** Low

### **Space Heating**

#### **General Operational Advice on Space Heating**

A reduction of 1°C on your thermostat can reduce annual space heating costs by 10% or more. An automatic timer switch or programmer allows you to schedule the heating duty on the hot water and heating system and to turn the system on and off as required. Use this facility to limit the running time for the heating system to fit your specific needs and you will save money.

Room thermostats normally turn the boiler and heating circulation pump off when the room temperature has reached the desired level. A room thermostat is normally located in a living area or circulations area (hall or landing). Guide temperature settings are 20°C for a living room and 16 - 18°C for circulation areas. However, the most appropriate setting depends on location of the thermostat and the heating system design. Choose the lowest setting that gives acceptable comfort conditions. Finding the setting to suit you may take some experimentation.

Thermostatic Radiator Valves (TRVs) can be set to suit the heating requirements of the room(s) in question.

For further details please refer to "A Detailed Guide to Home Heating Systems" available on [www.seai.ie](http://www.seai.ie)

### **Distribution System Losses and Gains (Control Category)**

The heating system controls in this dwelling could be improved.

The heating system would benefit from a programmer/timer and room thermostat to enable the boiler to switch off when no heat is required. A seven day programmer will allow you to customise a heating schedule to meet your specific heating needs for each day of the week. This would reduce the amount of energy used and lower your fuel bills.

Thermostatic radiator valves (TRVs) could also be installed to allow the temperature of each room to be controlled to suit individual needs, adding to comfort and reducing heating bills. For example, they can be set to be warmer in the living room and bathroom than in the bedrooms. TRVs should be fitted to every radiator excluding the radiator in the same room as the room thermostat and to the radiator/towel rail in the bathroom. The room thermostat is needed as well as the TRVs, to enable the boiler to switch off when no heat is required.

**Cost:** Medium    **Impact:** Medium

### **Main Heating System**

#### **General Operational Advice on Main Heating System**

You should have your boiler professionally serviced at least once per year. A clean and serviced appliance will operate more economically and will have a longer service life.

### **Efficiency of Main Heating System (Gas or Oil)**

This dwelling has an oil/gas main heating system. The efficiency of the boiler is greater than or equal to 70% but less than 80%.

If your boiler is over 15 years old and/or has an efficiency of less than 80% you should



consider upgrading it to a condensing boiler. A condensing boiler is capable of much higher efficiencies than other types of boiler, meaning it will burn less fuel to heat this dwelling. Boilers with an efficiency of over 90% are available on the market. While boiler upgrades can be undertaken at your own discretion, please note that, in the case of replacement boilers, it is a mandatory requirement under current Building Regulations that a replacement boiler has a minimum efficiency of 86%. When an old boiler is due for repair or replacement it is usually more cost effective to replace it with a condensing boiler. Condensing boilers need a drain for the condensate which may limit where they can be located. This can be borne in mind if you are considering remodelling the room containing the existing boiler even if the existing boiler is to be retained for the time being. Renewable or Low Carbon heat sources should also be considered as replacements for oil or gas boilers. Two such alternatives are biomass boilers and heat pumps. A biomass boiler burns renewable fuel such as wood pellets and therefore is less damaging to the environment than fossil fuels. Heat pumps transfer the heat stored in the ground or outside air into the home for heating or hot water. Biomass boilers could also be considered as a low carbon dioxide direct alternative to a gas or oil boiler. Biomass boilers usually require more fuel storage space than gas/oil boilers. Heat pumps could also be used to improve energy consumption levels but are not as easily retrofitted, particularly when the dwelling does not have underfloor heating.

**Cost:** High    **Impact:** High

### **Thermal Solar Panels**

This dwelling has no solar water heating.

Solar Panels, also known as "collectors", can be fitted to a building's roof. They use the sun's heat to warm water, or another fluid, which passes through the panel. The fluid is then fed to a heat store (e.g. a hot water tank) and helps provide hot water directly or can provide a source of hot water for the central heating system in the dwelling. Solar panels work throughout daylight hours, even if the sky is overcast and there is no direct sunshine. Solar panels can also be used to meet some space heating demand. Ideally the panels should be located on an unshaded, south facing roof at a tilt angle of 30°- 45° to the horizontal. Space will be need to accommodate an appropriately sized cylinder for the system and a thermal mixing (anti-scald) valve should also be installed.

**Cost:** High    **Impact:** Medium

### **PV Solar System or Microturbine**

This dwelling has no Photo Voltaics (PV) or Microturbine installed.

A solar photovoltaic (PV) system is one which converts light directly into electricity via panels placed on the roof with no waste and no emissions. This electricity is used throughout the home to supplement the electricity purchased from an energy supplier. Ideally the panels should be located on an unshaded, south facing roof at a tilt angle of 30°- 45° to the horizontal. Batteries can be used to store electricity from the PV array or wind turbine. However, this increases the installation and equipment cost as well as maintenance cost.

A Micro-windturbine is a small turbine placed on the property which uses wind to generate electricity. The electricity is used throughout the home to supplement the electricity from an energy supplier. The turbine should not be subject to wind shelter.